

OUTILLAGE WERKZEUG TOOLING HERRAMIENTAS



2028B

Clé pour serrer joint aiguille jusqu'à buse Ø 6.8
Schlüssel für Nadeldichtung bis Düse Ø 6.8
Wrench to tighten the needle gasket until nozzle Ø 6.8
Llave para apretar el sello de la aguja hasta boquilla Ø 6.8



2057T

Clé mâle coudée TORX 6
Schlüssel TORX 6
Wrench TORX 6
Llave hexagonal TORX 6



4036

Clé Allen 2.5 mm
Allenschlüssel 2.5 mm
Allen wrench 2.5 mm
Llave Allen 2.5 mm



4405E

Clé pour démontage piston
Schlüssel zum zerlegen des Kolben
Key for disassembling piston
Clave de desmontaje pistón



6845A

Collier serrage tuyau billes de verre
Klemmring Schlauch für Glasperlen
Clamping collar for glass beads hose
Abrazadera de tubo microesferas de vidrio